Wholehouse Fan Cover
For WINTER and SUMMER

Always Clean Both Surfaces Before Attaching Adhesive Strips

1. Clean surface of shutter and cover material thoroughly before attaching adhesive backed fastener.



Hook and loop come mated together.

2. 

Trim to length as necessary.

Peel off backing from loop side (soft fuzzy side) and attach along perimeter of shutter approximately ¼ inch from the edge. Firmly rub strip to shutter to get a good bond. Do for all four sides.

3. Peel off remaining backing.



4. 

Attach the insulated cover (silver side towards shutter) to the hook side (rough prickly side) leaving an overhang on all four sides.

5. Firmly rub to get a good bond.



6. Remove cover.

7. Trim excess cover material using fastener as a border.



8. Attach finished cover.

